

QUICK START GUIDE

It is vital to ensure that your new Rapidox SF6 6100 Portable analyser has the fuse correctly fitted. **If the fuse is not inserted correctly, the analyser will not operate.**

The analyser is supplied with one 3.15A 20mm anti surge fuse. This fuse will be found in small bag inside the netting of your analyser and will be clearly marked.

Take the fuse out of the bag and insert it into the fuse holder. Once in place, the fuse should look like this:



Once each fuse has been inserted into the holder, place the fuse into the analyser. The slot is clearly marked on the analyser:

