

## CAN-PIERCER for OXYBABY® V

www.wittgas.com

Product Information

Accessory for the easy measurement of oxygen in bottles and cans of various sizes in combination with the analyser OXYBABY® V

**Benefits:**

- minimal gas sample volume required
- reliable test results
- safe and simple operation
- adjustable for different sizes of bottles and cans
- sturdy design, unbreakable probe
- integrated needle protection
- for metal, PVC and glass containers

Please find further technical information about the measurement and the data administration on the OXYBABY® V data sheet.



\*analyser and bottle exclusive

**Preparation of the OXYBABY® V for application as a can-piercer:**

1. Unscrew the probe protection of the OXYBABY® V counterclockwise and take it off.
2. Take the probe off the OXYBABY® V and twist off the filter counterclockwise. Then attach the filter on the probe holder of the Can-Piercer.

**ATTENTION! The analyser is only to be operated with the special filter!**

3. Insert the OXYBABY® V into the holding brackets on the Can-Piercer.
4. Connect one end of the tube (connector with external thread) to the OXYBABY® V, and connect the opposite end of the tube to the filter on the probe holder of the Can-Piercer.
5. For further details please refer to the operating instructions of the OXYBABY® V.

Technical Data

<b>weigh:</b>	7,5 kg (without OXYBABY® V)
<b>dimesions:</b>	235 x 585 x 155 mm (packed, without OXYBABY® V)
<b>height of bottles and cans:</b>	max. 330 mm

(B3 subject to change)